

You need to drill through these 3 spacers for cable routing

From ½":

- 1 base
- 6 toes
- 1 reflector (1 ring, 2 plain fingers, 1 finger with joint)
- 2 curved arm segments
- 3 spacers with drilled hole
- 2 middle counterweight sections

From 1/4":

- 4 straight arm segments
- 2 elbow joints
- 2 wrist joints
- 2 shoulders
- 10 spacers with 1/2" centre hole
- 2 spacers with 1/4" centre hole
- 2 counterweight lid/base pieces

Please note: this will not work with anything other than 1/4" and ½" Ply/MDF.

If you don't wish to try and laser cut ½"- simply double up the required parts and cut 1/4".

A 5mm version will be done in the near future.

