

You need to drill through these 3 spacers for cable routing.

- From 1/2":  
 1 base  
 6 toes  
 1 reflector (1 ring, 2 plain fingers, 1 finger with joint)  
 2 curved arm segments  
 3 spacers with drilled hole  
 2 middle counterweight sections

- From 1/4":  
 4 straight arm segments  
 2 elbow joints  
 2 wrist joints  
 2 shoulders  
 10 spacers with 1/2" centre hole  
 2 spacers with 1/4" centre hole  
 2 counterweight lid/base pieces

Please note: this will not work with anything other than 1/4" and 1/2" Ply/MDF.

If you don't wish to try and laser cut 1/2"- simply double up the required parts and cut 1/4".

A 5mm version will be done in the near future.

